



This device is designed for use on an O.E. Primary chain tensioner on '07 & Later Big Twin (Also '06 Dyna). Improper use or installation voids all warranties.

1. Follow the Factory Service manual to remove the O.E. chain adjuster mechanism.
 2. Open the adjuster and set the ramp mechanism on the adjuster all the way back to allow the Bump-Stop to slide into position.
 3. Install the Bump-Stop underneath the tensioner shoe. The Bump-Stop will utilize the rear mounting hole of the Chain adjuster.
 4. Install the chain tensioner back into the primary and check the tension. Chain tension is now adjusted by grinding material away from the bump-stop using the pre-cut lines. If your chain tension is too loose, grind to the next line. This allows the tensioner block to ratchet up and increase the chain tension.
- *It is recommended to inspect the chain tension every 5,000 miles with your fluid change and service.**

